

TIME CLOCK SETUP

To Set Clock Time:

1. Remove cover from clock face
2. Press and hold CLOCK button then:
 - a. Press DAY to select correct day
 - b. Press HOUR to select correct hour
 - c. Press MIN to select correct minute
 - d. Release CLOCK button

To Set Program:

There are a total of 8 different ON/OFF programs available in the time clock. Each program can have different days of operation, different time for ON and time for OFF. Usually only program 1 is used, 2-8 are not used.

Turn ON time:

1. Press and release button TIMER. (program 1 ON time is displayed)
2. Press DAY and select day/s for program 1 to turn on.
3. Press HOUR to select hour for program 1 to turn on.
4. Press MIN to select minute for program 1 to turn on.

Turn OFF time:

1. Press and release button TIMER. (program 1 OFF time is displayed)
2. Press DAY and select day/s for program 1 to turn off.
3. Press HOUR to select hour for program 1 to turn off.
4. Press MIN to select minute for program 1 to turn off.

Press CLOCK to go back to run mode

Run Mode:

In run mode the cursor can be moved by pressing the MANUAL button

To Test Operation:

1. Use MANUAL button to move cursor over ON, RED light comes on to turn time clock on.
2. Use MANUAL button to move cursor over OFF, RED light goes off to turn time clock off.
3. When finished use MANUAL button to move cursor over AUTO.

If time clock is used to open gate, when ON (red light on) gate will open, when off (red light off) gate will time out then close.

If time clock is used to lock/unlock gate visitor buttons, when ON (red light on) gate is locked, when off (red light off) gate is unlocked.

Reset

To reset time clock and remove all programs, press the reset button above the MIN button.

Note: Cursor must be over AUTO for time clock to work